

EOS

Business Surveillance Solutions

17460 Silver Parkway • Fenton, MI 48430 • Phone (810) 433-3308 • Fax (810) 629-0711

4 Channel DVR Training Manual



Congratulations on Your
Partnership with EOS

Index

At the DVR

Remote Control.....	3
Watching Recorded Footage.....	4
Back-up.....	5
Review Back-Up	6-7
Naming your Cameras.....	8

REMOTE CONTROL

Handheld IR Controller Key Functions:



1. [QUAD]: Switch 4 Channels
2. [FWD]: Fast forward the video while playback. press [PLAY] to return to normal speed
3. [REV]: Reverse the video while playback, press [REV] to switch, press [PLAY] to return to normal speed
4. [POWER ON]: Reset the DVR to Power on and Power off mode. (standby and start up)
5. [LOGIN/LOCK]: If the security is enabled in the setup, use LOGIN/LOCK key to enter the user setup. It is important to remember the password due to without restoration function. Log in[to enter into “User ID select” and “Password” input interface]and lock functions [To exit setup and operation]
6. [OSD]: Press OSD for main menu
7. [PTZ]: Not supported
8. [EXIT]: Exit to the preview or return to the last menu
9. [RECORD]: Start manual record
10. [STOP]: Stop manual record

{0-9} keys: During setup, number keys are used to input values. For viewing channels 1, 2, 3 and 4, use 1, 2, 3 and 4 on numeric keypad respectively.

Up, Down directional keys: Move selection up and down in setup menu.

Left, Right directional keys: Move cursor left or right in setup menu.

Watching Recorded Footage

1. Push the menu/exit button on the front of the DVR.
2. Click the "SEARCH" icon.
3. Chose the date that you want to view from the box to the right of "RECORD FILE".
4. Click "SEARCH"
5. Times with recorded footage will be highlighted in RED.



6. The times are saved in half hour intervals.
7. Click on the time that you would like to review.
8. You can fast forward, pause, skip and rewind while the footage is being played.
9. To exit before the footage is done playing, simply click on the "X".

Back-up

1. First complete steps 1-7 in "View Events"
2. Click on "FILE LIST"



3. Find the times and camera that you would like to backup.
4. Use the buttons on the right hand side to find the time frame in which you would like to backup.
5. Click on the box to the right of every camera and time frame that you would like to backup.
 - a. Each camera has its own listing. Be sure for multiple cameras at the same time you chose each one.
6. A check will appear in the box when selected.
7. Insert a "USB flash drive" into the "USB 2.0" slot in the front of the DVR.
8. Click "BACKUP" on the right hand side.
 - a. Let it run.
9. When the backup is complete a window will appear saying "Backup is successful".
10. Click on "Sure" to clear this.
11. Click exit when you are done.
12. Click exit to get back to the main menu.
13. Click exit when you are all done to get out of the main menu screen.
14. Remove the USB device.

Review footage from your USB back-up

You must first install the “Playback” program before you can view your back-up!

Option 1: Insert the provided disk into your CD-ROM/DVD-ROM, Close Tray

Option 2: Go to Our website www.NOWYOUCANSEE.com, go to SUPPORT, FILE DOWNLOADS and download the file called “DVR SOFTWARE”.


1. Click on “My Computer”.
 - a. If “My Computer is not on your desktop, click on “start” and it wilol be in the upper right hand side of the pop-up.
2. Double click on the CD-ROM/DVD-ROM icon.
3. Click on the “Playbacksetup” icon.



4. A setup wizard will pop-up, click next.
5. Click “Next”
6. Click “Next”
7. Check the box to create a desktop icon, click next.
8. Verify that the information is correct and then click on “Install”
9. Let the program install, click “finished”.
 - a. If left checked the program will run after you click finished.


View backed up video

1. Leave the program running.
2. Put the “USB flash drive” into an open USB port on the computer.
3. Click on file at the top of window for the playback program.



4. Click on local Disk.
5. A window will open called “Browse for folder”
6. Click the plus sign next to your flash drives name.
7. Click once on the “RecordFile” and then click the “OK” button.


8. Click on play at the top of the window.



9. Click on play to review your back-up.
10. To increase or decrease the speed of the video, to stop, pause, click on the play button and chose the option that you want to use.

Name your Cameras

1. Push the menu/exit button on the front of your DVR.
2. Click on the “BASIC” icon.
3. Click the “DISPLAY” icon.
4. Chose the camera in which you would like to assign a specific name to.
 - a. Click on the box next to that camera.
 - b. Use the mouse/controller to type in a name for that camera (Max of 8 Characters).
 - c. Click the up arrow to clear the letter entry buttons.



5. Click “APPLY” to save the changes, then “SURE”.
6. Repeat steps 1-5 for each camera.
7. When done doing all the name entries click “EXIT”.